



Laminate flooring; Trendtime 8: Herringbone look

NOTE: The following additional information serves to optimise the given offset of the herringbone bars in the joint area at your own discretion.


1. Starting row:




2. Subsequent rows:




3. Alignment of bar offset:



4. Cutting the planks to length:



5. Finishing the row:



Please take note of the general installation rules in the pack leaflet.

Before installing the row, installation in a herringbone pattern requires the long side of the subsequent plank to be “averaged” in order to optimise the offset of the bars between the individual herringbone bars.

For this purpose, please fully read through the installation instructions before starting and take note of these accordingly:

1. Install the first row as described in the pack leaflet or advice section. Please bear in mind the necessary border spacing and also the minimum length of the “starting plank”, plus the other, general installation rules.
- 2.1 Bear in mind that each pack contains both left and right-hand versions of the planks for the herringbone look. Only use left-hand (or right-hand) planks consistently in a row and change the version when you start a new row, in order to achieve the herringbone look.
- 2.2 Start the installation of the next row with two whole planks, which are clicked into the row already installed on the long side with a bigger spacing to the left-hand wall (40-60 cm).
3. Position the slightly tilted planks (approx. 15-25°) by moving them sideways so that you optimise the bar transitions accordingly. Bear in mind that a smaller offset is permitted in this case and cannot be avoided. Then lower the plank at the desired position.
4. Now work out the length of the first cut plank and then cut the “starting plank” in this row to length. For this purpose, measure the gap between the wall and plank, as shown in Figure 4. Then cut a plank to the right length. Make sure to include the necessary wall clearance of approx. 8 mm in the calculation.
5. The first row can now be installed as described in the pack leaflet or advice section. When doing so, start with the plank cut to length. The steps described above are repeated...